Operating Instructions

Tumble dryer

ISE CD601W

Dear ISE customer!

Welcome to the family of ISE customers.

We hope that you will have many years of use from your new machine.

The machine has many special functions. To ensure that you get the most out of these functions, we recommend that you read the operating instructions before using the machine. The operating instructions contain information on how to avoid damaging the environment.

Contents

Before using your machine for the first time 3
- Do not tumble-dry 3

Safety instructions 4
- Installation 4
- Safety 4
- Interrupting a programme 4
- Transport/Winter storage 4
- Packing material 5
- Recycling 5

Child safety 6
- General 6

Description of the tumble dryer 7

Front panel 8

Advice and tips before you tumble-dry 9
- Have the clothes been spun? 9
- Materials that can be tumble-dried 9
- Materials that must not be tumble-dried 9
- Static electricity 9

Tumble drying 10
- Sort your fabrics 10
- Turn on the main power switch. 10
- Open the door, load the items and then close the door 10
- Select the programme 10
- Selecting Options 12
- Press the Start button 13
- Drying programme finished 13
- Once drying has finished 13

Care and cleaning 14
- Cleaning the lint filter 14
- Emptying the condensed water container 14
- Cleaning the outside of the machine 14
- Cleaning the condenser 15

Troubleshooting 16
- The machine will not start 16
- Overheating cut-out 16
- Drying takes too long 16
- The washing does not dry, or is too dry 16
- Error messages 16

Technical information 17
- Technical data 17
- Standard tests 17

Service 18
- Before contacting the service division 18

Installation 19
- Positioning the tumble dryer 19
- Adjusting the feet 20
- Condensed water 20
- Electrical installation 21

Door hanging 22
- Follow these instructions: 23

Quick guide 24
- Fabrics 24
- Turn on the main power switch 24
- Load the garments 24
- Select a programme and any options 24
- Press the Start button 24
- Drying programme finished 24
- Once drying has finished 24

Before using your machine for the first time

Do not tumble-dry

Certain materials are not suitable for tumble-drying. Always check and follow the instructions on each item's laundry label. You can find more information in the chapter "Advice and tips before you tumble-dry".

Note!

When starting the tumble dryer for the first time or after a long period without use, you may notice a slight thumping noise. This noise is completely normal and will disappear after a few loads.

See the Quick guide on the last page.

Safety instructions

Read the operating instructions and keep them in a safe place!



- Electrical installation, if required, should be carried out by a qualified electrician.
- The machine should only be used for tumble-drying as described in these instructions.
- Repairs and maintenance relating to safety or performance must be carried out by a qualified professional.
- Damaged mains cables must only be replaced by a qualified electrician.
- Sufficient ventilation is required to prevent smoke from open fires or fumes from equipment burning other fuels being sucked into the room when the tumble dryer is running.
- Do not dry dirty laundry in the tumble dryer.
- Items that are stained with e.g. cooking oil, acetone, alcohol, petrol, kerosene, stain remover, turpentine, wax and wax remover should be washed in hot water with extra detergent before they go in the tumbler dryer.
- Items such as foam rubber, latex, plastic, waterproof textiles, rubber-coated items and clothes and foam-rubber filled cushions must not be dried in the tumbler dryer.
- Fabric softener or similar products should be used as per the recommendations of the detergent manufacturer.
- The machine is not designed to be used by persons (even children) that are physically or mentally handicapped or lack experience and knowledge. Such persons must receive instruction in how to use the machine from the person responsible for their safety.
- Children must be watched to ensure they do not play with the machine.
- Do not let lint accumulate near the dryer
- Do not install the dryer behind doors with lock, sliding doors or next to the doors with hinges so that opening of the dryer door will never be hindered.

Caution!

Never stop a tumble dryer before the programme is completed unless you immediately remove all the laundry and spread it out so that the heat can disperse.

Installation

See the "Installation" chapter.

Safety

- The machine must not be used for drying items that have been dry-cleaned at home or fabrics that may contain residues of flammable liquids.
- The tumble dryer is protected by an overheating cut-out. This shuts off the machine if the temperature gets too high.
- A float shuts off the machine in the event of a blockage in the condensed water hose or if there is a risk of the condensed water container overflowing.

Caution!

When the tumble dryer is operating, the back of the tumble dryer will get very hot. Leave the machine to cool completely before touching the back.

Interrupting a programme

You can stop a drying programme by:

- Open the door. The drum will then then stop automatically.
- Press the main power switch.
- Press the Stop button for three seconds.

When you want to resume tumble-drying, simply close the door and press the Start button.

Transport/Winter storage

If you need to move your machine or store it over the winter in unheated premises, make sure that you drain the condensed water container beforehand.

Safety instructions

Packing material

Please sort waste materials in accordance with local guidelines.

Recycling

This machine is manufactured and labelled for recycling. In order to prevent injuries, the machine must be made unusable once the decision has been taken to dispose of it. Contact your local authority for information about where and how your machine can be recycled correctly.

Child safety

General

Do not allow children to play with the tumble dryer.

The tumble dryer does not start automatically when the door is closed (if a child pulls the door shut from the inside, for example).

Description of the tumble dryer



1. Main power switch
2. Condensed water container
3. Panel
4. Type plate
5. Lint filter holder
6. Outer door
7. Fan (behind hatch)
8. Condenser
9. Lint filter



Front panel



1 Main power switch
2 Programme selector
3 Options buttons
4 Display window
5 Start
6 Stop

Advice and tips before you tumble-dry

Here are some tips that may help you before you begin tumble-drying.

Have the clothes been spun?

Items to be tumble-dried should be spun at 1000 rpm or faster. Higher spin speeds save both energy and drying time.

Materials that can be tumble-dried

This symbol means that the material is suitable for tumble-drying. Fabrics best suited to tumble-drying are cotton fabrics, terry cloth and synthetic fibres. Garments will be softer and lighter when tumbled than when hung out to dry.

Note!

The tumble dryer does not cause any significant wear to fabrics. The lint that is trapped in the lint filter consists of dust and fibre residues which form when the items are used.

Materials that must not be tumble-dried

This symbol means that the material is not suitable for tumble-drying. Certain materials may melt or become a fire hazard if exposed to heat, and others can lose their shape or shrink.

And do not tumble-dry

- materials labelled "Do not dry near heat".
- garments that have been dry-cleaned at home.
- plastic foam.
- fibreglass material.
- wool must not be tumble-dried because of the risk of felting.

Static electricity

To reduce the risk of static electricity in the laundry after tumble drying you can:

- Use fabric softener when washing.
- Wait five minutes after the drying program ends before opening the door and removing the laundry from the dryer.

Note!

If the door is opened during the programme, the programme will be interrupted and will return to the start. The clothes may be too damp or too dry as a result.

Tumble drying

Below are step-by-step instructions to help you achieve the best possible tumble-drying results.

1 Sort your fabrics

You will achieve the most uniform drying results if the items are made of the same type of material. Do up zips and buttons, fasten belts, sort the items and adjust the load and temperature.

2 Turn on the main power switch.

3 Open the door, load the items and then close the door

4 Select the programme

Guidelines as to what specific programmes can be used for.

Auto extra dry

This programme is for items that are particularly difficult to dry, e.g. jeans with very thick seams.

Note!

Knitted fabrics in particular are prone to shrinkage. Use the Auto dry, Auto normal dry or Auto Iron dry programmes for these items. Stretch clothes back into shape immediately after drying.

Auto dry and Auto normal dry

These programmes shut off the heat once the load is dry but before it is "over dry". The Auto dry programme shuts off the heat slightly later than Auto normal dry. Use trial and error to find out what works best. Use these programmes when you want items to be completely dry.

Auto Iron dry

This programme shuts off the heat once the load is just damp enough for ironing or pressing.

Time programme

The programme length you choose depends on what you intend to do with the items after drying them. Use trial and error to find out what works best. When you use Timed dry to tumble-dry a load of mixed fabrics, some of the garments may remain damp. Tumble-dry any damp garments for a further 30 minutes or so using the Timed dry programme.

Note!

When using the Timed dry programme, garments can become “over-dry” if you have selected too long a drying time. This can cause the items to shrink or crease and become rough. Synthetic materials can also become charged with static electricity.

Revitalise

Use the Air fluff programme when you just want to refresh, air or soften up items.

Specify the programme time by pressing the button with the time symbol. The time is shown on the display and you can choose a programme time between 30 minutes and 3 hours.

Tumble drying

Programme chart

Here we present a few examples of the energy and time consumption of a few different programme settings. Consumption can vary according to room temperature, humidity, load, variations in the power supply and selected options

For the consumption values given below, the requirements are as follows:

Temperature of intake air:	23°C
Moisture content of intake air:	55 %
Drying temperature:	Normal or low
Heater output:	2500W

Programme chart

Program	Material	Temperature	Max. load (kg)	Energy consumption (approx. kWh)		Programme time (approx. hrs and min.)	
				800 rpm	1600 rpm	800 rpm	1600 rpm
Auto extra dry	Cotton, linen	Normal	7.0	4.5	3.3	2:00	1:35
Auto dry	Cotton, linen	Normal	7.0	4.2	3.3	1:50	1:30
Auto dry	Crease-resistant, polyester/cotton	Normal	3.5	1.9	-	0:55	-
Auto normal dry	Cotton, linen [1)]	Normal	7.0	3.9	2.8	1:40	1:15
Auto normal dry	Crease-resistant, polyester/cotton	Normal	3.5	1.7	-	0:45	-
Auto normal dry	Acrylic, rayon, acetate	Low	3.5	2.0	-	1:15	-
Auto Iron dry	Cotton, linen	Normal	7.0	3.0	2.2	1:35	1:10

[1] This programme is EN 61121 compliant. During testing, the tumble dryer shall have a 16A connection and Time saver shall be activated.

Energy and time consumption in compliance with EN 61121.

Tumble drying

5 Selecting Options

By selecting options, you can tailor a drying programme to suit your requirements. The machine remembers which options you choose for each programme and uses them (with one exception – Delayed Start) the next time you select the same programme. You can, of course, change this if you want.

Temperature

You can choose Temperature Low with all programmes except Revitalise.

- Select Temperature Low by pressing the button next to the symbol.
- The lamp next to the button lights when Temperature Low is selected.

Time saver

You can choose Time saver with all programmes except Revitalise. The programme is shortened by about 12 minutes.

- Press the button next to the symbol.
- The lamp next to the button lights when Time saver is selected.

Anti crease

This option means that the drum will rotate for three seconds per minute for two hours after the drying programme has finished. The option prevents the fabrics from remaining in the same position and becoming creased, if you are unable to remove them immediately after tumble-drying has finished. Cannot be selected with the Air fluff programme.

- Select Anti crease by pressing the button next to the symbol.
- The lamp next to the button lights when Anti crease is selected.

Delayed Start

First select which programme you want to use and then select Delayed Start by pressing the button next to the symbol. The display shows Delayed Start in whole hours. Press the button to select a delayed start of 1 to 24 hours. The lamp next to the button lights when Delayed Start is selected. Press the Start button, the machine counts down 1 hour at a time and starts after the selected delay. This option cannot be used with the Timed dry or Air fluff programmes.

Tumble drying

6 Press the Start button

Stopping or changing a programme

Press and hold button the Stop button for three seconds.

Note!

The programme will not be affected if you change the programme selector after the programme has started.

Loading or removing washing

You can stop the tumble dryer after starting a programme by opening the door. Load more washing or take out the items you want, close the door and press the Start button. A new estimate of the remaining programme time will be displayed after a few minutes.

7 Drying programme finished

The text "End" appears on the display when the programme is finished. If the Anti crease option has been selected, the drum will rotate for three seconds per minute for two hours after the programme is finished.

Condensed water

The condensed water container must be drained after each load. Remove the condensed water container, empty out the water and replace the container. If the condensed water container becomes full to overflowing, the programme is interrupted. Empty the container and press the Start button to continue the programme.

Note!

Do not remove the condensed water container while the machine is running.

Tip!

As the condensed water is decalcified, it can be used in steam irons. Pour it through a coffee filter.

Automatic emptying

If you want the water to empty automatically, see the "Installation" chapter.

Important!

- Clean the lint filter after each load. See the "Care and cleaning" chapter.
- Empty the condensed water container after each load.

Caution! ⚠

If the lint filter becomes clogged, the machine's automatic overheating cut-out may be triggered. In order to be able to restart the machine, you must clean the filter and allow the machine to cool down for around 30 minutes.

8 Once drying has finished

Turn off the main power switch. Remove the clothes and close the door to prevent small children from climbing into the machine.

Care and cleaning

Cleaning the lint filter

The lint filter must be cleaned after each load. If you have very hard water, this can cause limescale deposits in the lint filter. Check for any limescale deposits when cleaning the lint filter and, if necessary, wash the filter by hand.

1. Grasp the filter handle and pull it towards you.
2. Pull the filter out of its holder.



3. Open the filter and remove the lint from all sides of it by hand. Use a soft, dry cloth to remove any deposits.



4. Replace the filter in its holder.

Note!

If you have hard water, the filter should be washed with water to get rid of any limescale deposits. Use a sponge and a little dishwashing detergent if necessary. Dry the filter carefully with a towel. If you cannot remove the limescale, you can buy a new filter from the retailer where you bought the tumble dryer.

Emptying the condensed water container



The condensed water container must be drained after each load. Remove the condensed water container, empty out the water and replace the container.

If the condensed water container becomes too full, the programme is interrupted and F10 is shown in the display. Empty the container and press the Start button to restart the programme.

Cleaning the outside of the machine

Clean the outside of the machine and the programme panel with a mild cleaner. Do not use solvents, as these can damage the machine. Do not hose down or spray the machine with water.

Note!

Do not allow dust to accumulate around the machine. Keep the area around the tumble dryer clean and cool; dust, heat and moisture prolong drying times.

Care and cleaning

Cleaning the condenser

The condenser should be cleaned at least three times a year. If you have pets, the condenser must be cleaned more frequently.

1. Turn off the main power switch.

2. Remove the lower plinth.



3. Open the condenser panel by turning the two knobs anticlockwise.



4. Remove the condenser and rinse the lamella springs clean using a hand-held shower, for example. Do not touch the lamella springs, as you may damage the condenser. Do not use pointed metal objects during cleaning.



Note!

Do not put the condenser in a dishwasher.

5. Replace the condenser. When refitting the condenser, check that it is replaced correctly. The top of the condenser is marked "upp", "up" and "oben".



6. Replace the plinth.

Troubleshooting

The machine will not start

Check

- that the door is properly closed.
- that the main power switch is on.
- that the Delayed Start option has not been selected. If so, the time remaining until the start will be shown in full hours in the display (e.g. 5, 4, 3h). To cancel Delayed Start, press the Start/Stop button for 3 seconds.
- that the plug is connected.
- that the fuses (circuit breakers) in your house are intact. Swap two circuit breakers over to make sure. You cannot always tell from the outside if a circuit breaker is broken.
- that the overheating cut-out has not been triggered (see below).

Overheating cut-out

The overheating cut-out shuts off the tumble dryer if the temperature is too high, e.g. because dust is clogging the lint filter.

- Clean the lint filter.
- Check also that the condensed water container is not full and, if necessary, clean the condenser. See the chapter “Care and cleaning”.
- The overheating cut-out will reset automatically once the machine has cooled down.

Drying takes too long

- Empty the condensed water container and check that neither the lint filter nor the condenser are clogged. See the chapter "Care and cleaning".
- Overly long drying times may also be due to the tumble dryer being located in a confined area or room that is too small, causing the air to become too hot.
- Make sure that the tumble dryer has access to more cold air, open doors and/or windows.

The washing does not dry, or is too dry

- The door has been opened while the programme is running, which disrupts the moisture monitoring function.

Error messages

If F10 flashes in the display, the condensed water container is full. Empty the container and restart the programme.

If F30 is flashing in the display, the maximum permitted programme time has been reached. Read "Drying takes too long" in the "Troubleshooting" chapter to find out what to do.

Technical information

Technical data

Height:	850mm
Width:	595mm
Depth:	585mm
Weight:	47kg
Cylinder volume:	111l
Max. drying capacity:	7kg
Speed:	52 rpm
Rated power:	See type plate.
Drum material:	Stainless steel
Outer casing material:	Powder-coated and hot-galvanized sheet steel or stainless steel.
Setup	Stacking or freestanding
Drain:	1.7m polypropylene hose 3/4 BSP connection 2.0m rubber hose

Standard tests

Europe:

Drying performance:	EN 611 21 (95/13/EEC).Programme 3 Auto normal dry, 7kg cotton, temperature Normal, Time saver. The machine has been tested for 1-Phase 16 A.
Energy declaration:	EN 611 21 (95/13/EEC).Programme 3 Auto normal dry, 7kg cotton, temperature Normal, Time saver. The machine has been tested for 1-Phase 16 A. For switching between 10 A and 16 A, see the "Electrical installation" chapter.
Test method for noise measurement:	IEC 60 704-2-6.

Service

Before contacting the service division

Before contacting the service division, you should find out whether you can resolve the fault yourself. See the "Troubleshooting" and "Care and cleaning" chapters.
If you still need to contact the service division, make sure that you know the model designation, type designation and serial number.
The model designation can be found in the stamped hole on the first page of the operating instructions and on the machine's panel. The type designation and serial number can be found on the type plate.



Installation

Positioning the tumble dryer

The tumble dryer can be free-standing or in a stack. Remember that the tumble dryer produces heat and should therefore not be located in a room that is too small. If the room is very small, drying will take longer due to the limited quantity of air.

Caution! ⚠

- Any electrical installation must be carried out by qualified professionals.
- The machine must not be installed behind a lockable door, a sliding door or a door with hinges on the opposite side to those of the tumble dryer.
- The tumble dryer's plinth ventilation must not be blocked by a rug or the like.

Tip!

To improve ventilation, leave the door to the room where the tumble dryer is located open.

Freestanding

The tumble dryer can be positioned beside the washing machine.

Stacking

The tumble dryer can be placed on top of a ISE washing machine. In this case you use the stacking attachments (foot cups and anti-tilt devices) that come with the machine. You will find two foot cups in a bag in the drum and two anti-tilt devices are attached to the bottom left corner at the back of the machine. Extending plates can be ordered from your local retailer.

How to assemble the stack:

1. Undo the anti-tilt device.



2. Undo the two screws indicated on the back of the washing machine.



3. Secure the anti-tilt device using the screws as shown in the picture.



4. Attach the plastic cups for fixing the tumble dryer's front feet to the washing machine's top cover. This is essential, as only when the tumble dryer's feet are resting in the plastic cups can you be sure that the dryer is correctly positioned on the washing machine.

   Break off tag A on the cup fitted on the right-hand side and tag B on the cup fitted on the left-hand side. Then remove the paper from the self-adhesive surface under the plastic cups.



Installation

5. Fit the plastic cups so that the “tags” marked with arrows are against the front edge or side edge of the cover and press them firmly onto the cover. Then break off the remaining tags.



6. Push out the knock-out hole on the back of the dryer (you must not remove it, just open it) using a hammer and screwdriver.



7. Push the tumble dryer in under the metal brackets. At the same time keep the front edge raised by 10mm to 20mm.



8. Lower the tumble dryer’s front feet into the plastic cups and adjust the dryer to ensure that it is balanced.



Adjusting the feet

Screw the feet in or out so that the tumble dryer is steady and balanced on the floor or on the washing machine. Then tighten the lock nuts.



Condensed water

The machine is supplied as shown in Option 1 (inset). This means that the condensed water is pumped into the condensed water container. This must then be removed and emptied by hand.

Option 2 allows you to remove the small short hose from the nipple. Attach the rubber hose supplied to the same nipple. The water can then be pumped out into a sink or a floor drain (2a).



Installation

Electrical installation

Connect the machine by plugging it into an earthed wall socket. The electrical wall socket must be placed outside of the installation area to be easily accessible.

Connection on delivery

The machine is supplied as 1-Phase, 230V, 50Hz, heat output 2500W and has a 16A plug. Any residual current devices must be type A.

Switch-over

It is possible to switch over from 16 A (heat output 2500W) to 10 A (heat output 1950 W).

The switchover must be performed by a qualified electrician.

1. Turn off the machine using the main power switch.
2. Press and hold the Anti crease button and then press the main power switch.
3. If the upper right LED next to the programme selector and the LED next to the Anti crease button light up, the machine is connected for 10 A and 1950 W.
   If both the upper and lower right LEDs next to the programme selector and the LED next to the Anti crease button light up, the machine is connected for 16 A and 2500 W.
   Press the Time saver button once to switch the heat output.
4. Press the Stop button to save your selection.

Repeat steps 1 to 4 to restore the machine to its original heat output.

Door hanging



1. Hinge pins (top and bottom)
2. Cover washer
3. Plastic plugs (on the upper and lower edges)
4. Locking hook
5. Hinges (left + right side)
6. Plinth

Door hanging

You can choose whether the door is hung on the right or the left.

Follow these instructions:

1. Remove the plinth.

2. Remove the hinge, two screws.

3. Lift the door up and remove it. Support the door at the same time.

4. Remove both door pins (top and bottom). Fit them on the other side of the machine. Refit the hinge.



5. Loosen and remove the catch (lift up and pull out) and the cover plate on the door and the machine. Switch the catch and the cover plate.

6. Move the plastic plugs on the upper and lower edges of the door. Use a flat-bladed screwdriver to remove the plugs.
7. Refit the door by loosening the hinge screws slightly, affixing the door and closing it. Retighten the hinges. Replace the plinth.

Quick guide

1 Fabrics
- Dry fabrics of the same type together to ensure that they dry as evenly as possible.

2 Turn on the main power switch

3 Load the garments
- Close the door.

4 Select a programme and any options
- Turn the programme selector to the required programme.
- Select any options and settings.

5 Press the Start button

6 Drying programme finished
- "End" appears on the display when the programme is finished. If the Anti crease option has been selected, the drum will rotate for three seconds per minute for two hours after the drying programme is finished.
- Clean the lint filter after each load.
- Empty the condensed water container.

7 Once drying has finished
- Turn off the mains power switch and close the door.

Art. No.: 80 902 00. Rev. 01. We reserve the right to make changes.
Printed on environmentally friendly paper that meets the requirements of MIljöförbundet and Naturskyddsföreningen.

CE